

Learning Environments user guide: Arts Centre-319

Arts Centre-319 is an eSeminar Room located on the 3rd floor of the Arts Centre building on the Parkville campus. It contains the following equipment:

- Dual boot Mac mini – runs Windows XP and OS X
- Data projector
- DVD
- VCR
- Cassette deck
- Amplifier
- Two slide projectors
- Overhead projector.

The Mac, DVD, VCR, cassette deck, amplifier and remote controls are all located in the cupboard labelled "Audio Visual Rack". You need a LEC key to open this cupboard.

Turning on the data projector

1. Point the remote control at the projector & press the green button.
 - The projector takes a minute or two to warm up.
2. Select the correct input channel on the projector by pressing the **Input** button.

NOTE: The projector has 3 input channels. The active channel is displayed in the top right corner of the projection screen – press the **Input** button to scroll through these inputs.

Device	Input
Mac mini.....	INPUT A
DVD/VCR.....	VIDEO
Not used.....	S-VIDEO



**Data projector
remote control**

Amplifier settings

The amplifier is located at the bottom of the audio visual rack. It serves two purposes:

1. Amplifying the audio of all connected devices.

- All audio is routed through the amplifier.
- You **must** ensure the amplifier is turned on and that the correct input is selected.
- Change input channels using the **Input Selector** knob.
- Adjust volume using the **Volume** knob.

2. Switching the projected image between the DVD and video.

- The DVD & video use the same channel on the data projector (the **Video** input).
- Selecting **DVD** or **VCR1** with the amplifier's **Input Selector** knob routes the selected device's image to the data projector and audio to the room's speakers.
- You must ensure that the data projector is set to the **Video** input!
- Read "Turning on the data projector" for instructions on turning on the projector & selecting the correct input.

Amplifier input settings

Device	Input
Mac.....	CD
Video.....	VCR1
DVD.....	DVD
Cassette.....	TAPE

Using the Mac mini

Read the user guide for using Mac minis in learning spaces at:

<http://www.infodiv.unimelb.edu.au/tss/access/macmini.html>

The Mac is located in the cupboard labelled "Audio Visual Rack". You need a LEC key to open this cupboard.

1. Press the power button on the Mac.
2. Turn on the data projector and select **Input A**.
 - Read "Turning on the data projector" for instructions on turning on the projector & selecting the correct input.

Mac audio

1. Turn on the amplifier
 2. Select the **CD** input using the **INPUT SELECTOR** knob.
 3. Adjust volume using the **Volume** knob.
- Read "Amplifier settings" for instructions on turning on the amplifier & selecting the correct input.

Playing a DVD

The DVD player is located in the cupboard labelled "Audio Visual Rack" - you need a LEC key to unlock this cupboard.

1. Turn on the data projector.
2. Select the **Video** input.
 - Read "Turning on the data projector" for instructions on turning on the projector & selecting the correct input.
3. Load your disc into the DVD player.
4. Use the controls on the DVD player's front panel to play your DVD.

DVD audio

1. Turn on the amplifier.
2. Select the **DVD** input using the **Input Selector** knob.
3. Adjust volume using the **Volume** knob.
 - Read "Amplifier settings" for instructions on turning on the amplifier & selecting the correct input.

Playing a video tape

The video player is located in the cupboard labelled "Audio Visual Rack".

1. Turn on the data projector.
2. Select the **Video** input.
3. Read "Turning on the data projector" for instructions on turning on the projector & selecting the correct input.
4. Load your video tape into the video player.
5. Use the controls on the videos' front panel to play your video tape.

Video audio

1. Turn on the amplifier
2. Select the **VCR1** input using the **INPUT SELECTOR** knob.
3. Adjust volume using the **Volume** knob.
 - Read "Amplifier settings" for instructions on turning on the amplifier & selecting the correct input.

Playing a cassette

The cassette deck is located in the cupboard labelled "Audio Visual Rack". The cassette deck occupies the right hand section of the combination CD/cassette player.

1. Load your cassette into the cassette deck.
2. Use the controls on the cassette deck's front panel to play your cassette.

Cassette audio

1. Turn on the amplifier.
 2. Select the **TAPE** input using the **INPUT SELECTOR** knob.
 3. Adjust volume using the **Volume** knob.
- Read "Amplifier settings" for instructions on turning on the amplifier & selecting the correct input.

Using the slide projectors

There are two carousel slide projectors located at the rear of the room. Load your carousel onto the projector(s).

Remote controls are labelled & located in the drawer in the audio visual rack. Use these to turn on and display your slides.

Using the overhead projector

Switch on the overhead projector (OHP) using the switch on the front of the unit.

If the OHP does not appear to be working, it may have blown a bulb.

- Use the globe changing switch located on the front of the OHP to change to the spare globe.

Please report any errors or omissions in this user guide to:

les-guides@unimelb.edu.au

The University of Melbourne has used its best endeavours to ensure that material contained in this publication was correct at the time of printing. The University gives no warranty and accepts no responsibility for the accuracy or completeness of information and the University reserves the right to make changes without notice at any time in its absolute discretion. Users of this publication are advised to reconcile the accuracy and currency of the information provided with the relevant department of the University before acting upon or in consideration of the information. Copyright in this publication is owned by the University and no part of it may be reproduced without the permission of the University